



Touch Sensor

Shock Sensor

Button

Touch Sensor

Infrared Sensor

Speaker

**Touch Sensor
(On the back)**

Vibration Motor

Microphone

Magnetic Pogo Pin